

MANUFACTURER Portwest, Westport, Co Mayo, Ireland

NAME AND ADDRESS OF THE NOTIFIED RODY HAVING ISSUED FC CERTIFICATE

INSPECINTERNATIONAL ITD - NR-0194 MODELS -PWSS/PSSS/PCSS/PSS2 56 LESLIE HOUGH WAY, SALFORD, GREATER MANCHESTER, M6 6AJ, UK BSI GROUP THE NETHERLANDS B.V. - NR:2797

MODELS:PW51/PV50/PV54/PV60/PV64/PW9/

AUTODROME DE LINAS-MONTLHÉRY BP 20212 - 91311, MONTLHÉRY CEDEX, FRANCE SATRA TECHNOLOGY CENTRE - NR · 0321 MODELS · PSSO

WYNDHAM WAY, TELFORD WAY, KETTERING, NORTHAMPTONSHIRE, NN16 8SD, UK CSI SPA-NR+ 0497 MODELS - PSS1

VIA LOMBARDIA, 20-20021 BOLLATE (MI)ITALY

MODELS:

PW55/PS55/ PB55/PC55	Endurance Helmet (Vented)
PW97	Monterosa Safety Helmet(Vented)
PSS2	Full Brim Future Helmet
PW51	Expertbase PRO Safety Helmet
PSS0	Arrow Safety Helmet (Vented)
PV50 / PV60	Peak View Hard Hat Vented
PV54 / PV64	Peak View Plus Hard Hat - Electrical Properties

EN SAFETY HELMETS

Refer to the product label/markings for detailed information on the corresponding standards. Only standards and icons that appear on both the product and the user information below are applicable. All these products comply with the requirements of Regulation EU 2016/425, EN397:2012+A1:2012.

This PPE is intended to be used as to protect the users against falling objects and consequential brain injury and skull fracture. This helmet shell of the head protection is designed for protecting the users from 1) dropped object from the above of head 2) falling objects 3) Impacts at very Low temperature (-30°C); 4) lateral deformations; Please do not use this helmet for climbing activities, fire-fighting activities and sporting activities.
USAGE OF THE PROTECTIVE HELMET:

For adequate protection this helmet must fit or be adjusted to the size of the user's head. Use the back-wheel knob to adjust to the appropriate size: TTurn right to close / adjust smaller size; Turn left to open / adjust bigger size. Use the 4 pins on the headgear to adjust the wearing height. Move the pins on the appropriate holes: 3 different height positions on the front side and 2 different height positions on the back side of the headgear. Open the closure clip and pull the tape to straps to adjust the chin strap's length.
The helmet is made to absorb the energy of a blow by partial

destruction or damage to the shell and the harness, and even though such damage may not be readily apparent, any helmet subjected to severe impact should be replaced.

The attention of users is also drawn to the danger of modifying or removing any of the original component parts of the helmet, other than as recommended by the helmet manufacturer. Helmets should not be adapted for the purpose of fitting attachments in any way not recommended by the helmet manufacturer. Do not apply paint, solvents, adhesives or self-adhesive labels, except

ince with instructions from the helmet manufacturer. ELECTRICAL LIMITS OF USE AND PRECAUTIONS BEFORE USE, the user has to check that the electrical limits of the

helmet correspond to the nominal voltage it is likely to encounter during use. Insulating helmet should not be used in situations where there is a risk which could partially reduce its insulating properties (i.e.mechanical or chemical aggression). Electrical insulation performances are only granted if this helmet is not used alone: it is necessary to use other insulating protective equipment according to the risks involved in the work

if the helmet becomes dirty or contaminated, particularly on the external surface, it should be carefully cleaned in accordance with cleaning recommendations below (maintenance/storage). We highlight the potential risk of loss of protection in case of iate cleaning and ageing of the helmet

ADJUSTMENT AND INSPECTION OF THE PROTECTIVE HELMET In order to ensure effective protection, this helmet should be worn with its peak forward (sit in straight position) and it should be adjusted to the user's head size (do not fit too loose or too tight) by its adjustment system located at the rear of the helmet. The helmet life is affected by several factors, such as cold, heat, chemical

products (e.g. corrosive reagent, paint, cleaner etc.), sun light or misuse. Daily and before any use a check should be performed in order to identify any sign of rendering (cracks, flaws) the helmet, its harness and accessories fragile. Any helmet having been subject to a strong shock or having wear signs should be replaced. If it has no defaults, it is therefore proper for the intended use. The manufacturing date is marked inside each helmet shell. Under normal usage conditions, this protective helmet should provide roper protection for 7 years according to the manufacturing date. MAINTENANCE / STORAGE

This protective helmet may be cleaned and disinfected by means of a cloth impregnated in a low concentration cleaning solution. Don't use any abrasive or corrosive chemical product. If this helmet cannot be cleaned by using this method, it should be replaced. The product must be transported in its packaging unit. If there is no packaging unit, use packaging that protects the product from shock, exposure to moisture, thermal hazards, exposure to light, holding it away from any product or material or substance that can deteriorate it When it is not used anymore or during transportation, the helmet

should be stored in a dry cool place away from light, frost and in a location granting that no chemical product or sharp object bends it by falling above. It should not be compressed or stored close to any source of heat. It is recommended that the storage temperature is kept in the range 20±15°C. This helmet does not include any substance known to be susceptible of causing allergies. However if a sensitive person has an allergic reaction, they sho therefore leave the hazardous area, remove the helmet and ask for medical advice.

Missing or deficiently respect of instructions of use, adjustment/ inspections and maintenance/storage, may limit effectiveness of insulation protection The harness and chin strap are not replaceable. Discard the helmet

and replace new if the chin strap found damage. There are two long rectangle holes on both sides of shell is for accessories. Such as installing the ear muff. Please read carefully the earmuff use instruction, before installing the earmuff on to this helmet and to confirm the ear muff has been tested with this helmet and its compatibility

MARKINGS



Manufacturer Identification Markings indicating compliance with the health and

safety requirements of Regulation (EU)2016/425
EN 397:2012+A1:2012 = Referring standard and year of

publication 6

Plastic recycling symbol Helmet Shell Material ABS = (ABS-Acrylonitrile butadiene styrene)

20 D = Year and Month of manufacture (on the example:2019/March)

MARKING (FACULTATIVE TESTING)

Helmets bearing one of the following markings meet the additional requirements as below:

-30°C: Very low temperature
The helmet keeps its performance above these temperatures
440V.a.c.: Electric insulation

The helmet protects the user against a short accidental contact with electric leads under voltage which may reach 440Va.c. For general use in industry and in working seat where there is the electrical risks below 440V.a.c.

LD: Lateral deformation.

The helmet protects the user against lateral deformations