

GLOBESTOCK Engineering Ltd. Mile Oak Ind. Estate, Maesbury Rd., Oswestry, Shropshire SY10 8GA Tel: 01691 654966 Fax: 01691 661726

EC Type Examination: SGS United Kingdom Ltd Ellesmere Port Wirral CH65 3EN Notified Body No. 0120

USER INSTRUCTIONS G-TRIPOD - GSE210 S.W.L 136Kg

Tripod Assembly

Unfold the two hinged legs until the spring location pins engage thus locking the legs into place.

Leg heights are altered by means of the leg adjustment clips, aligning the various holes in the leg tubes and inserting the said clips to secure.

To disassemble reverse the above procedures pulling the spring location pins pull rings upwards to free the hinged legs.

Mounting Equipment

A G-Saver II or Winch can be mounted onto the fixed tripod leg using the brackets provided. The wire rope being fed through the staggered slot in the pulley bracket and through the slotted rope guide, rotating the locking ring to secure the rope.

An additional underslung anchorage point is provided in the form of an eye nut. This is to permit the use of a second or alternative piece of equipment if required.

Tripod Positioning

A formal risk assessment should be made to establish both the suitability of the equipment and the location in which it is to be installed. This should be carried out by a suitably qualified engineer.

The Tripod should be mounted on a suitably stable surface in such a manner that it cannot accidentally become dislodged or unstable during use.

Position the tripod so that all feet are minimum distance of 30cm from the edge of the opening in which entry is being made.

Inspection

Before use and during assembly the tripod should be inspected for signs of cracking, damage, severe corrosion and that all fittings and fasteners are present and secure.

The tripod should be examined by a competent person other than those using the equipment every 3 to 6 months dependant upon the operating environment. The results of which should be recorded on the accompanying INSPECTION RECORD CARD or similar document, see reverse. In the case of major faults being observed the tripod must be returned for service.

We recommend this equipment is returned for service and test to ourselves or an authorised service agent on an annual basis. Arrangements to do this can be made through your supplier.

<u>Statement</u>

This product has been tested to EN795 and is intended for single person use with a suitable shock absorber element to EN355 being employed as means of fall arrest.

INSPECTION G-TRIPOD (OVE	INSPECTION RECORD CARD G G-TRIPOD (OVERHEAD PULLEY) SI					e	
MODEL: 210 Date of 1st Use: Serial No:	DATE					Record Service & Reco	cation.
GENERAL	All fasteners present & secure						
CONDITION	No severe corrosion/damage						
Rubber Feet	Secure - Rubber Present						
	No Significant Wear/damage						
Legs	Not Bent, Damaged or cracked						
	Fixed securely to Head Castings						
	Extend & Retract						
Leg Adjustment	Present & No Damage						
Clips	Locate Securely						
Head /	No Damage or Cracks						
Leg Castings	Legs open smoothly						
Head Locking	Locks Legs Open						
Pins	Operate freely - no damage						
	Adequate spring force						
Pulley and	No Damage						
Pulley Bracket	Operation satisfactory						
Rope Guide/	No Significant Wear						
Locking Ring	Locks Rope into Head						
Comments							

Issue: 001