



• In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl re	commends an
inspection every 12 months and after any exceptional event in the life of the product.	

PPE inspection should be conducted with the manufacturer's Instructions for Use.
Download the instructions at PETZL.COM.

FRAME-LOADED ROPE CLAMP

User information

Surname

Address

Identifier

PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

Manufacturer: Petzl, Zl Cidex 105A - 38920 Crolles - France

Good condition (G)	Contraction (TM)	To repair (TR)	Do not use, retire (R)			N/A applicable	
1. Known product history Usage conditions or exceptional event fall or fall arrest, use or storage at extre modification outside manufacturer's fac	me temperatures,							
				\oslash	Q	X	× U	N/A
2. Preliminary observations • Verify the presence and legibility of the • Verify that the product lifetime has noi • Compare with a new device to verify the		ments.						
 3. Checking the condition of the frame Check the condition of the frame (marks, wear, cracks, deformation, corrosion). Check the condition of the attachment holes (marks, deformation, cracks, corrosion). Check for wear caused by rope running through the device. For the TIBLOC, check that all teeth are present and check their state of wear. The teeth must not be fouled. If necessary, clean them with a brush. For CROLLs manufactured after February 2017, check that the wear indicator is not visible. 								
 4. Checking the cam (only on BASIC, CROLL, ASCENSION, ASCENTREE) • Check the condition of the cam (marks, deformation, cracks, corrosion). Check that all teeth are present and check their state of wear. The teeth must not be fouled. If necessary, clean them with a brush. • Check the condition of the cam axle and rivet (marks, deformation, cracks, corrosion). • Check the cam's rotation and the effectiveness of the return spring. 								
		-						
6. Function checkVerify that the rope clamp slides along	g the rope in one direction and locks in th	ne other direction.						

Comments (detail here any defects found on the product and accomplished tasks)								
VER	VERDICT Inspected by							
	Product fit to remain in service		Company					
	Product unfit to remain in service		Date	Next inspection date				